MICROMEGA

Le son de France

Windows 10

Windows 10 : MyDAC driver install

Dear client,

Thank you buying the Micromega MyDAC digital-to-analog converter. This document was made so you can get the maximum from your MyDAC with your Windows 10 computer (new or after update from Windows 7/8/8.1).

MyDAC USB input works in two modes (refer to backpanel switch on the product) :

• **USB Audio Class 1.0**, no need for specific driver, it will work with audio file up to **24-bit / 96 kHz**.

• **USB Audio Class 2.0**, you will need to install a specific driver that will allow you to use audio file up to **24-bit / 192 kHz.**

ⓘ **You have updated your computer to Windows 10 lately ?** Please follow this document from page 3.

ⓘ **You have a new computer already using Windows 10 ?** Please follow this document from page 8.

Enjoy the music !

Team Micromega

1. Uninstall former driver

MICROMEGA

Le son de France


Recycle Bin
USER
Most used
Get Started
Get Skype
Maps
People
Calculator
Alarms & Clock
Coup d'oeil sur les activités
Calendar
Mail
Microsoft Edge
Photos
Search
Globalement...
17°
20°
12°
Paris
Phone Compa...
OneNote
Jouer et explorer
Xbox
Music
Movies & TV
Ces pays qui souffrent le plus de la chute du pétrole
Money
News
Store
Microsoft Solitaire Collection
Get Office
File Explorer
Settings
Power
All apps
Settings
Control Panel
Open startup menu and click on **Settings**
Search the web and Windows
ENG
10:36 AM
9/1/2015


Settings
SETTINGS
Find a setting
System
Display, notifications, apps, power
Devices
Bluetooth, printers, mouse
Network & Internet
Wi-Fi, airplane mode, VPN
Personalization
Background, lock screen, colors
Accounts
Your account, sync settings, work, other users
Time & language
Speech, region, date
Ease of Access
Narrator, magnifier, high contrast
Privacy
Location, camera
Update & security
Windows Update, recovery, backup
Click on **System**
Search the web and Windows
Show hidden icons
ENG
10:37 AM
9/1/2015


Settings
SYSTEM
Find a setting
Display
Notifications & actions
Apps & features
Multitasking
Tablet mode
Battery saver
Power & sleep
Storage
Offline maps
Default apps
About
Apps & features
Manage optional features
Search, sort, and filter by drive. If you would like to uninstall or move an app, select it from the list.
Type an app name...
Sort by install date
Show apps on all drives
MyDac v1.56.0
Micromega
Unavailable
01/09/2015
Uninstall
MyHarmony
Unavailable
Microsoft Corporation
28/08/2015
From the **Apps and features** tab, find the MyDAC driver, select it and uninstall



If the User Account Control is active, choose **Yes**.

Click on **Uninstall** to continue.

Click on **Finish** to close.

2. MyDAC driver install on Windows 10

MICROMEGA

Le son de France


Recycle Bin
USER
Most used
Get Started
Get Skype
Maps
People
Calculator
Alarms & Clock
Coup d'oeil sur les activités
Calendar
Mail
Microsoft Edge
Photos
Search
Globalement...
17°
20°
12°
Paris
Phone Compa...
OneNote
Jouer et explorer
Xbox
Music
Movies & TV
Ces pays qui souffrent le plus de la chute du pétrole
Money
News
Store
Microsoft Solitaire Collection
Get Office
File Explorer
Settings
Power
All apps
Settings
Control Panel
Open startup menu and click on **Settings**
Search the web and Windows
ENG
10:36 AM
9/1/2015


Settings
SETTINGS
Find a setting
System
Display, notifications, apps, power
Devices
Bluetooth, printers, mouse
Network & Internet
Wi-Fi, airplane mode, VPN
Personalization
Background, lock screen, colors
Accounts
Your account, sync settings, work, other users
Time & language
Speech, region, date
Ease of Access
Narrator, magnifier, high contrast
Privacy
Location, camera
Update & security
Windows Update, recovery, backup
Click on **Update & Security**
Search the web and Windows
Show hidden icons
ENG
10:37 AM
9/1/2015


Settings
UPDATE & SECURITY
Find a setting
Windows Update
Windows Defender
Backup
Recovery
Activation
For developers
Reset this PC
If your PC isn't running well, resetting it might help. This lets you choose to keep your files or remove them, and then reinstalls Windows.
Get started
Advanced startup
Start up from a device or disc (such as a USB drive or DVD), change Windows startup settings, or restore Windows from a system image. This will restart your PC.
Restart now
From the Recovery tab, click on **Restart Now**
Search the web and Windows
ENG
10:37 AM
9/1/2015


Choose an option
Continue
Exit and continue to Windows 10
Troubleshoot
Reset your PC or see advanced options
Click on **Troubleshoot...**


Troubleshoot
Reset this PC
Lets you choose to keep or remove your files, and then reinstalls Windows.
Advanced options
... then **Advanced options ...**


Advanced options
System Restore
Use a restore point recorded on your PC to restore Windows
Command Prompt
Use the Command Prompt for advanced troubleshooting
System Image Recovery
Recover Windows using a specific system image file
Startup Settings
Change Windows startup behavior
Startup Repair
Fix problems that keep Windows from loading
Go back to the previous build
... then Startup Settings...


Startup Settings
Restart to change Windows options such as:
Enable low-resolution video mode
Enable debugging mode
Enable boot logging
Enable Safe Mode
Disable driver signature enforcement
Disable early-launch anti-malware protection
Disable automatic restart on system failure
Restart
... and finally Restart


Startup Settings
Press a number to choose from the options below:
Use number keys or functions keys F1-F9.
1) Enable debugging
2) Enable boot logging
3) Enable low-resolution video
4) Enable Safe Mode
5) Enable Safe Mode with Networking
6) Enable Safe Mode with Command Prompt
7) Disable driver signature enforcement
8) Disable early launch anti-malware protection
9) Disable automatic restart after failure
EightForums.com
Press F10 for more options
Press Enter to return to your operating
Press «7» on your keyboard

Once your computer has started, go to the driver folder, make a right-click on the **setup.exe** file. Click on **Properties** and **Compatibility.**



Select Windows 7 in **Compatibility Mode**

Apply and **OK**

Launch setup.exe



If the User Account Control (UAC) is active, choose **Yes.**



Start install by clicking on **Next**

Check that the «USB Audio Class» switch is on **Class 2.0**

Plug the MyDAC to your computer and use the wheel to power it ON and check that the USB light in ON.

NB : If the MyDAC was already plugged into your computer, unplug it and plug it again.



Use the default destination folder and **Install**



Click on **Install this driver anyway.** This message will appear twice.





Please wait a moment while installation complete itself.

Click on **Finish.**



Go into **Sound Settings** and **Playback tab.**

Do a **right-click on Micromega MyDac USB Audio** and select **Default device.**

Apply, **OK** and now enjoy your music !